# PORTABLE PICTURES POPCORN INSTRUCTIONS

- Turn all switches on; L = rotating arm, C = heating element, R = light.
- For first batch only let kettle warm up for a couple of minutes.
- Lift lid of kettle.
- Add a glug of oil into kettle.
- Add 8oz (1 cup or 1 level scoop) of corn kernels to kettle.
- For sweet popcorn add a few shakes of glaze to the kettle. If you want salted popcorn you must add the salt to the corn after it has been cooked and removed from the kettle.
- Close kettle lid, shut door of machine and allow to pop.
- As popcorn cooks it will push open the lid of the kettle and fall to the bottom of machine.
- Listen for popping sound to stop.
- Turn off the left hand switch (rotating arm). Unless you are cooking another batch straight away also turn off the centre switch (heating element).
- Open the door, lift the lid and empty the kettle by twisting the handle.

### DO NOT ADD SUGAR OR SALT DIRECTLY TO THE KETTLE

### EMPTY KETTLE IMMEDIATELY AFTER POPPING STOPS OR IT WILL BURN

### TURN OFF LEFT & CENTRE SWITCHES WHEN MACHINE IS NOT IN USE

## THANK YOU FOR USING PORTABLE PICTURES

WWW.PORTABLEPICTURES.CO.UK / INFO@PORTABLEPICTURES.CO.UK / 07984 149416 OR 07968 109985